



Index

A

abort command
 description A-2
 diagnostics A-3
 examples A-2
Address Resolution Protocol
 See ARP
addresses
 IP 2-5
 link-layer and IP 3-26
 subnetting 2-7
allow filter 3-19
analyzing the quality of links 4-7
ARP
 cache 3-26
 mapping addresses 3-26
 proxy routers 3-26
 See also link-layer addresses
arp add subcommand 3-26, A-4
arp command
 description A-4
 diagnostics A-6, A-127
 examples A-5
arp drop subcommand A-5
arp flush subcommand A-5
arp publish subcommand 3-26, A-5
arp reset subcommand A-5
arp reverse subcommand A-5
Assigning Multiple IP Addresses 3-14
associated networks, identifying 3-17

C

cd command
 description A-7

 diagnostics A-7
 examples A-7
channel
 See radio channel
checking the log 4-4
close command
 description A-9
 examples A-9
commands
 monitoring, table 4-2
 TALnet, table A-1
configuration file
 opening from console 3-7
 opening remotely 3-8
 reloading from console 3-32
 reloading remotely 3-33
 sample 3-1
configuration overview
 TALnet software 3-5
configuring your router
 overview 3-5
 planning 2-1
 worksheet 2-12
console
 See service console
conventions, in document xvi
copy command
 description A-10
 diagnostics A-10
 examples A-10

D

delete command
 description A-12
 diagnostics A-12
 examples A-12

device command
 description A-13
 diagnostics A-19
 examples 3-14, A-18
device config command 3-13
device config subcommand A-13
device kill subcommand A-16
device make subcommand 3-13, A-16
device show subcommand A-18
devices
 configuration example 3-14
 configuration overview 3-13
 configuring 3-13
 creating 3-13
 packet 3-13
dir command
 description A-21
 examples A-21
disallow filter 3-19
displaying statistics, monitoring commands 4-2
DNS
 and IP addresses 2-8
 configuration example 3-16
 description 2-8, 3-15
 identifying servers 3-15
 name resolution, figure 2-9
 resolving IP addresses 3-15
 See also domain names
document
 audience xv
 conventions xvi
 organization xv
 purpose xv
 related information xvi
domain addserver subcommand 3-15, A-22
domain cache clean subcommand A-22
domain cache list subcommand A-22
domain cache load subcommand A-23
domain cache only subcommand A-23
domain cache save subcommand A-23
domain cache size subcommand A-23
domain cache wait subcommand A-24
domain command
 description A-22
 diagnostics A-26
 examples A-25
domain dropserver subcommand A-24
domain list subcommand A-24
Domain Name System
 See DNS
domain names
 description 2-8
 hierarchy, figure 2-9
 specifying 3-16
 See also DNS
domain query subcommand A-24
domain retry subcommand A-25
domain suffix subcommand 3-16, A-25
domain trace subcommand A-25
dynamic routing 2-10, 3-17

E

echo accept subcommand A-27
echo command, description A-27
echo refuse subcommand A-27
Ethernet interface
 configuration example 3-14
 link-layer address 3-26
 parameters 2-5
 subnet masks 2-6
 with two IP addresses 3-15
exit command
 description A-28
 examples A-28

F

frequency
 See transmission frequency
ftp command
 description A-29
 examples A-36

G

global parameters
 hostname 3-9
 specifying 3-9
 system contact 3-9
 system location 3-9
glossary D-1

H

help command
 description A-37
 examples A-37
hop check subcommand 4-5, A-38
hop command
 description A-38
 examples A-39
hop maxttl subcommand 4-5, A-38

hop maxwait subcommand 4-5, A-39
hop queries subcommand A-39
hop trace subcommand A-39
hostname
 determining 2-1
 setting 3-9
hostname command
 description 3-9, A-41
 examples A-42

I

icmp command
 description A-43
 examples A-44
icmp echo subcommand A-43
icmp status subcommand A-43
icmp trace subcommand A-44
If 3-12
iface command
 description A-45
 diagnostics A-50
 examples 3-14, A-49
iface config subcommand 3-14, A-45
iface create subcommand A-48
iface delete subcommand A-48
iface kill subcommand A-48
iface make subcommand 3-13, A-49
iface show subcommand A-49
interfaces
 and devices 3-13
 configuration example 3-14
 configuration overview 3-13
 configuring existing 3-14
 creating 3-13

IP

addresses
 and DNS names 2-8, 3-15
 class formats 2-5
 Ethernet interface 3-15, A-45
 overview 2-5
 wireless interface 3-11, A-104
filtering packets 3-24–3-26
IP addresses
 multiple 3-14
ip command
 description A-52
 examples A-54
ip filter subcommand 3-24, A-52
ip pool subcommand A-54
ip rtimer subcommand A-54
ip status subcommand A-54
ip ttl subcommand A-54

K

key authentication 3-21
key command
 description A-56
 examples A-57
key config subcommand 3-21, A-56
key create subcommand 3-21, A-56
key delete subcommand 3-22, A-57
key sequences
 console connections 3-7
 Telnet connection 3-8
kick command
 description A-58
 diagnostics A-59
 examples A-58

L

link quality
 testing 4-7
 testing for TCP traffic 4-9
 testing for UDP traffic 4-7
 viewing information on radio links 4-10
link-layer acknowledgments A-115
link-layer addresses
 Ethernet interface 3-26
 mapping to IP addresses 3-26
 wireless interface 2-2
 See also ARP
loadgen command
 description 4-7, A-60
 examples A-60
log command
 description A-61
 examples A-61
log console subcommand A-61
log -f subcommand A-61
log session subcommand A-61
log stop subcommand A-61
log, checking 4-4
logging on after user authorization is set 3-5
logout command
 description A-63
 example A-63

M

Management Information Base
 See MIBs

memory command
 description A-65
 examples A-66
memory freelist subcommand A-65
memory ibufsize subcommand A-65
memory nibufs subcommand A-66
memory sizes subcommand A-66
memory thresh subcommand A-66
MIBs
 and SNMP 4-12
 supported 4-12
 TALnet proprietary B-1
mkdir command
 description A-67
 diagnostics A-67
 examples A-67
monitoring
 and SNMP 4-11–4-13
 list of commands 4-2
 ping 4-4
 traceroute 4-5
Multiple IP Addresses 3-14
multiple IP addresses 3-14

N

neighbor address identification 3-19
neighbors, identifying 3-17
network
 monitoring 4-1
 supported applications 1-2

O

output power
 See power level

P

packets
 filtering examples 3-25
 filtering on addresses 3-25
 filtering on type 3-24
 filtering overview 3-24
per-link power
 example 3-12
 setting 3-12
physical addresses
 See link-layer addresses
ping command
 changing length 4-5

description A-68
examples A-69
sending multiple 4-5
sending single 4-4
ping facility, testing system 4-4
PN code
 determining 2-5
 setting 3-11
power level
 determining 2-3
 setting default 3-11
 setting per link 3-12
 table 2-4, A-107
process check subcommand A-71
process command
 description A-71
 examples A-72
process status subcommand A-71
process trace subcommand A-71
proprietary MIB
 channel table B-9
 general definitions B-1
 local variables B-2
 neighbor table B-5
 product section B-2
 radio table B-3
 sample B-1–B-11
pseudorandom noise code
 See PN code
pwd command
 description A-74
 examples A-74

R

radio channel, configuring 3-11
radio parameters
 configuration example 3-12
 configuring 3-10
 determining 2-2
reboot command
 description A-75
 examples A-75
received signal strength
 See RSS
rename command
 description A-77
 diagnostics A-77
 examples A-77
repeat command
 description A-79
 examples A-79
Requests For Comments
 See RFCs

reset command, description A-80
 RFCs
 list of xvi
 RFC 1058 2-10
 RFC 1155 4-12
 RFC 1166 2-6
 RFC 1212 4-12
 RFC 1213 4-12
 RFC 1354 4-12
 RFC 1443 4-12
 RFC 1573 4-12
 RFC 1723 2-11
 RFC 1724 4-12
 RIP
 description 2-10
 modifying neighbor table 3-18
 sample routing table 2-11
 rip accept subcommand A-82
 rip add subcommand 3-18, A-83
 rip classless subcommand A-83
 rip command
 description A-82
 diagnostics A-84
 examples A-84
 rip drop subcommand A-83
 rip merge subcommand A-83
 rip refuse subcommand A-84
 rip request subcommand A-84
 rip status subcommand A-84
 rip trace subcommand A-84
 rmdir command
 description A-86
 diagnostics A-86
 examples A-86
 route add subcommand 3-17, A-88
 route addprivate subcommand 3-17, A-89
 route command
 description A-88
 diagnostics A-89
 examples A-89
 route drop subcommand A-89
 route flush subcommand A-89
 route lookup subcommand A-89
 router configuration
 blank worksheet 2-13
 planning 2-1
 sample worksheet 2-14
 routing
 associated networks 3-17
 dynamic 2-10, 3-17
 static 2-10, 3-17
 tables
 adding default 3-17
 adding static 3-17
 overview 2-10
 Routing Information Protocol
 See RIP
 RSS
 analyzing 4-5
 displaying 4-6
 See also per-link power

S

security
 enabling for wireless neighbors 3-18
 key authentication 3-21
 neighbor address identification 3-19
 user authorization 3-22
 serial console
 See service console
 service console
 and xvi editor C-1
 displaying network statistics 4-2
 key sequences, table 3-7
 session command, description A-90
 signal strength
 See RSS
 Simple Network Management Protocol
 See SNMP
 SNMP
 community strings 2-2
 overview 4-11
 sending requests 4-13
 supported MIBs 4-12
 supporting 4-12
 variables
 system contact 2-2, 3-9
 system location 2-2, 3-9
 snmp command
 description A-92
 examples A-94
 snmp community add subcommand 4-12, A-93
 snmp community delete subcommand A-93
 snmp community show subcommand A-93
 snmp syscontact subcommand 3-9, A-94
 snmp syslocation subcommand 3-9, A-94
 software configuration, overview 1-2
 spreading code
 See PN code
 start command, description A-95
 start discard subcommand A-95
 start echo subcommand A-95
 start ftp subcommand A-95
 start rip subcommand A-96
 start snmp subcommand 4-12, A-96
 start telnet subcommand A-96
 static routing 2-10, 3-17
 statistics, displaying 4-2

stop command, description A-97
stop discard subcommand A-97
stop echo subcommand A-97
stop ftp subcommand A-97
stop rip subcommand A-97
stop snmp subcommand A-98
stop telnet subcommand A-98
subnet masks
 determining 2-7
 overview 2-6
subnetting
 See subnet masks

system contact
 defining 3-9
system location
 defining 3-9
system prompt, setting 3-9
system, testing connectivity 4-4

T

talk debug all subcommand A-99
talk debug command, description A-99
talk debug errors subcommand A-99
talk debug events subcommand A-99
talk debug neighbors subcommand A-99
talk debug packets subcommand A-99
talk debug quality subcommand A-100
talk debug states subcommand A-100
talk radio address subcommand 3-12, A-102
talk radio analyze subcommand 4-6, A-103
talk radio channel subcommand 3-11, A-103
talk radio command
 description A-101
 diagnostics A-108
 examples A-106
talk radio ip-address command 3-11, A-104
talk radio neighbor allow subcommand A-104
talk radio neighbor disallow subcommand A-104
talk radio neighbor hear subcommand A-105
talk radio neighbor ignore subcommand A-105
talk radio neighbor MW subcommand 3-12, A-105
talk show allowfilters subcommand A-111
talk show command
 description A-111
 examples A-113
talk show debug subcommand A-111
talk show ignorefilters subcommand A-111
talk show neighbors subcommand A-112
talk show quality command 4-10
talk show quality subcommand A-112
talk show radio subcommand A-112
talk show rss subcommand 4-6, A-112
talk show timers subcommand A-112

talk tune acks subcommand A-115
talk tune command A-115
TALnet software
 commands, table A-1
 configuration overview 1-2, 3-5
 monitoring commands, table 4-2
 standard application support 1-2
 standard network protocols 1-2
 TALtalk overview 1-1
talnet.cfg
 See configuration file
TALtalk protocol, overview 1-1
tcp ceiling subcommand A-116
tcp command
 description A-116
 examples A-119
tcp floor subcommand A-116
tcp irrt subcommand A-117
tcp kick subcommand A-117
tcp limit subcommand A-117
tcp mss subcommand A-117
tcp reset subcommand A-118
tcp rtt subcommand A-118
tcp status subcommand A-118
tcp syndata subcommand A-118
tcp trace subcommand A-118
tcp window subcommand A-119
telnet command
 description A-121
 examples A-121
Telnet, key sequences, table 3-8
terms, defined D-1
time command
 description A-122
 examples A-122
tip command
 description A-123
 diagnostics A-123
trace ascii subcommand A-126
trace broadcast subcommand A-126
trace command
 description A-125
 examples A-126
trace hex subcommand A-126
trace input subcommand A-125
trace off subcommand A-125
trace output subcommand A-125
trace raw subcommand A-126
traceroute, testing network 4-5
transmission frequency
 determining 2-3
 setting 3-11
 table 2-3, A-106
two radio configuration
 Configuring Radio Parameters 3-10

two-radios
 configuring 3-10

U

udp command
 description A-128
 examples A-129
UDP packet generator keys 4-8
UDP packet receiver keys 4-9
upd receive command
 description 4-7
udp receive subcommand A-128
udp send subcommand A-128
upd send command
 description 4-7
uptime command
 description A-130
 example A-130
user authorization 3-22
user command
 description A-131
 examples A-133
user config subcommand 3-22, A-132
user create subcommand 3-22, A-132
user delete subcommand A-132
user kill subcommand A-132
user make subcommand A-133
user show subcommand A-133
users
 adding 3-22
 authorization flags 2-12, 3-22, A-131, A-132
 changing authorization options 3-22
 defining 2-12
 defining authorization 3-22

V

version command
 description A-134
 examples A-134
view command
 description A-135
 examples A-135
view session, navigating, table A-135
viewing information on radio link quality 4-10

W

who command
 description A-136

examples A-136
wireless interface
 configuration example 3-12
 configuring 2-2, 3-10
 IP address 3-11, A-104
 link-layer address 2-2
 PN code 2-5
 power level 2-3
 transmission frequency 2-3
wireless neighbor security 3-18
worksheet
 configuration 2-12

X

xvi editor, using C-1-C-3

