



Index

A

abort command
 description A-2
 diagnostics A-2
 examples A-2
Address Resolution Protocol
 See ARP
addresses
 IP 2-5
 link-layer and IP 3-18
 subnetting 2-7
ARP
 cache 3-18
 mapping addresses 3-18
 proxy routers 3-19
 See also link-layer addresses
arp add subcommand 3-19, A-4
arp command
 description A-4
 diagnostics A-6, A-107
 examples A-5
arp drop subcommand A-4
arp flush subcommand A-4
arp publish subcommand 3-19, A-5
arp reset subcommand A-5
arp reverse subcommand A-5
associated networks, identifying 3-14

C

cd command
 description A-7
 diagnostics A-7
 examples A-7

channel
 See radio channel
close command
 description A-8
 examples A-8
commands
 monitoring, table 4-1
 TALnet, table A-1
configuration file
 opening from console 3-5
 opening remotely 3-6
 reloading from console 3-24
 reloading remotely 3-25
 sample 3-1
configuration overview
 TALnet software 3-4
configuring your router
 overview 3-4
 planning 2-1
 worksheet 2-12
console
 See service console
conventions, in document xvi
copy command
 description A-9
 diagnostics A-9
 examples A-9

D

delete command
 description A-10
 diagnostics A-10
 examples A-10

device command
 description A-11
 diagnostics A-15
 examples 3-12, A-15
 device config command 3-11
 device config subcommand A-11
 device kill subcommand A-13
 device make subcommand 3-11, A-13
 device show subcommand A-15
 devices
 configuration example 3-12
 configuration overview 3-11
 configuring 3-11
 creating 3-11
 packet 3-11
 dir command
 description A-18
 examples A-18
 displaying statistics, monitoring
 commands 4-1
 DNS
 and IP addresses 2-8
 configuration example 3-13
 description 2-8, 3-12
 identifying servers 3-12
 name resolution, figure 2-9
 resolving IP addresses 3-12
 See also domain names
 document
 audience xv
 conventions xvi
 organization xv
 purpose xv
 related information xvi
 domain addserver subcommand 3-12, A-19
 domain cache clean subcommand A-19
 domain cache list subcommand A-19
 domain cache load subcommand A-19
 domain cache only subcommand A-20
 domain cache save subcommand A-20
 domain cache size subcommand A-20
 domain cache wait subcommand A-20
 domain command
 description A-19
 diagnostics A-22
 examples A-22
 domain dropserver subcommand A-20
 domain list subcommand A-21
 Domain Name System
 See DNS
 domain names
 description 2-8
 hierarchy, figure 2-9
 specifying 3-13
 See also DNS

domain query subcommand A-21
 domain retry subcommand A-21
 domain suffix subcommand 3-13, A-21
 domain trace subcommand A-21
 dynamic routing 2-10, 3-14

E

echo accept subcommand A-23
 echo command, description A-23
 echo refuse subcommand A-23
 Ethernet interface
 configuration example 3-12
 link-layer address 3-18
 parameters 2-5
 subnet masks 2-6
 exit command
 description A-24
 examples A-24

F

frequency
 See transmission frequency
 ftp command
 description A-25
 examples A-30

G

global parameters
 hostname 3-7
 IP addresses 3-7
 specifying 3-7
 system contact 3-7
 system location 3-8
 glossary D-1

H

help command
 description A-31
 examples A-31
 hop check subcommand 4-4, A-32
 hop command
 description A-32
 examples A-33
 hop maxttl subcommand 4-5, A-32
 hop maxwait subcommand 4-5, A-32

hop queries subcommand A-33
hop trace subcommand A-33
hostname
 determining 2-1
 setting 3-7
hostname command
 description 3-7, A-34
 examples A-34

I

icmp command
 description A-36
 examples A-37
icmp echo subcommand A-36
icmp status subcommand A-36
icmp trace subcommand A-36
iface command
 description A-38
 diagnostics A-43
 examples 3-12, A-42
iface config subcommand 3-12, A-38
iface create subcommand A-41
iface delete subcommand A-41
iface kill subcommand A-41
iface make subcommand 3-11, A-41
iface show subcommand A-42
interfaces
 and devices 3-11
 configuration example 3-12
 configuration overview 3-11
 configuring existing 3-12
 creating 3-11
Internet Protocol
 See IP
IP
 addresses
 and DNS names 2-8, 3-12
 class formats 2-5
 overview 2-5
 specifying system 2-2, 3-7
 wireless interface 2-2, 3-7
 filtering packets 3-16–3-18
ip address subcommand 3-7, A-45
ip command
 description A-45
 examples A-47
ip filter subcommand 3-16, A-45
ip pool subcommand A-47
ip rtimer subcommand A-47
ip status subcommand A-47
ip ttl subcommand A-47

K

key sequences
 console connections 3-5
 Telnet connection 3-6
kick command
 description A-48
 diagnostics A-48
 examples A-48

L

link-layer acknowledgments A-95
link-layer addresses
 Ethernet interface 3-18
 mapping to IP addresses 3-18
 wireless interface 2-2
 See also ARP
log command
 description A-50
 examples A-50
log console subcommand A-50
log -f subcommand A-50
log session subcommand A-50
log stop subcommand A-50
logout command
 description A-52
 example A-52

M

Management Information Base
 See MIBs
memory command
 description A-53
 examples A-54
memory freelist subcommand A-53
memory ibufsize subcommand A-53
memory nibufs subcommand A-53
memory sizes subcommand A-54
memory thresh subcommand A-54
MIBs
 and SNMP 4-7
 supported 4-7
 TALnet proprietary B-1
mkdir command
 description A-55
 diagnostics A-55
 examples A-55

monitoring
and SNMP 4-6–4-8
list of commands 4-1
ping 4-4
traceroute 4-4

N

neighbors, identifying 3-14
network
monitoring 4-1
supported applications 1-2

O

output power
See power level

P

packets
filtering examples 3-18
filtering on addresses 3-17
filtering on type 3-17
filtering overview 3-16
per-link power
example 3-10
setting 3-10
physical addresses
See link-layer addresses
ping command
changing length 4-4
description A-56
examples A-57
sending multiple 4-4
sending single 4-4
ping facility, testing system 4-4
PN code
determining 2-5
setting 3-9
power level
determining 2-3
setting default 3-9
setting per link 3-10
table 2-4, A-88
process check subcommand A-59
process command
description A-59
examples A-60
process status subcommand A-59
process trace subcommand A-59

proprietary MIB
channel table B-9
general definitions B-1
local variables B-2
neighbor table B-5
product section B-2
radio table B-2
sample B-1–B-10
pseudorandom noise code
See PN code
pwd command
description A-62
examples A-62

R

radio channel, configuring 3-9
radio parameters
configuration example 3-10
configuring 3-8
determining 2-2
reboot command
description A-63
examples A-63
received signal strength
See RSS
rename command
description A-65
diagnostics A-65
examples A-65
repeat command
description A-66
examples A-66
Requests For Comments
See RFCs
reset command, description A-67
RFCs
list of xvi
RFC 1058 2-11
RFC 1155 4-7
RFC 1166 2-6
RFC 1212 4-7
RFC 1213 4-7
RFC 1354 4-7
RFC 1443 4-7
RFC 1573 4-7
RFC 1723 2-11
RFC 1724 4-7
RIP
description 2-10
modifying neighbor table 3-15
sample routing table 2-11
rip accept subcommand A-68
rip add subcommand 3-15, A-68

rip command
 description A-68
 diagnostics A-70
 examples A-70
rip drop subcommand A-69
rip merge subcommand A-69
rip refuse subcommand A-69
rip request subcommand A-69
rip status subcommand A-69
rip trace subcommand A-69
rmdir command
 description A-71
 diagnostics A-71
 examples A-71
route add subcommand 3-14, A-72
route addprivate subcommand 3-14, A-72
route command
 description A-72
 diagnostics A-73
 examples A-73
route drop subcommand A-73
route flush subcommand A-73
route lookup subcommand A-73
router configuration
 blank worksheet 2-13
 planning 2-1
 sample worksheet 2-14
routing
 associated networks 3-14
 dynamic 2-10, 3-14
 static 2-10, 3-14
tables
 adding default 3-14
 adding static 3-14
 overview 2-10
Routing Information Protocol
 See RIP
RSS
 analyzing 4-5
 displaying 4-5
 See also per-link power

S

serial console
 See service console
service console
 and xvi editor C-1
 displaying network statistics 4-1
 key sequences, table 3-5
session command, description A-74
signal strength
 See RSS

Simple Network Management Protocol
 See SNMP
SNMP
 community strings 2-2
 overview 4-6
 sending requests 4-8
 supported MIBs 4-7
 supporting 4-8
 variables
 system contact 2-2, 3-7
 system location 2-2, 3-8
snmp command
 description A-76
 examples A-78
snmp community add subcommand 4-8, A-77
snmp community delete subcommand A-77
snmp community show subcommand A-77
snmp syscontact subcommand 3-7, A-77
snmp syslocation subcommand 3-8, A-78
 software configuration, overview 1-2
spreading code
 See PN code
start command, description A-79
start discard subcommand A-79
start echo subcommand A-79
start ftp subcommand A-79
start rip subcommand A-79
start snmp subcommand 4-8, A-80
start telnet subcommand A-80
static routing 2-10, 3-14
statistics, displaying 4-1
stop command, description A-81
stop discard subcommand A-81
stop echo subcommand A-81
stop ftp subcommand A-81
stop rip subcommand A-81
stop snmp subcommand A-81
stop telnet subcommand A-82
subnet masks
 determining 2-7
 overview 2-6
subnetting
 See subnet masks
system contact
 defining 3-7
system location
 defining 3-8
system prompt, setting 3-7
system, testing connectivity 4-4

T

talk debug all subcommand A-83
talk debug command, description A-83
talk debug errors subcommand A-83
talk debug events subcommand A-83
talk debug neighbors subcommand A-83
talk debug packets subcommand A-83
talk debug states subcommand A-83
talk radio address subcommand 3-9, A-84
talk radio analyze subcommand 4-5, A-85
talk radio channel subcommand 3-9, A-86
talk radio command
 description A-84
 diagnostics A-89
 examples A-87
talk radio neighbor hear subcommand A-87
talk radio neighbor ignore subcommand A-87
talk radio neighbor MW subcommand 3-10, A-87
talk show command
 description A-92
 examples A-93
talk show debug subcommand A-93
talk show neighbors subcommand A-92
talk show radio subcommand A-92
talk show rss subcommand 4-5, A-92
talk show timers subcommand A-93
talk tune acks subcommand A-95
talk tune command A-95
TALnet software
 commands, table A-1
 configuration overview 1-2, 3-4
 monitoring commands, table 4-1
 standard application support 1-2
 standard network protocols 1-2
 TALtalk overview 1-1
talnet.cfg
 See configuration file
TALtalk protocol, overview 1-1
tcp ceiling subcommand A-96
tcp command
 description A-96
 examples A-99
tcp floor subcommand A-96
tcp irtt subcommand A-97
tcp kick subcommand A-97
tcp limit subcommand A-97
tcp mss subcommand A-97
tcp reset subcommand A-98
tcp rtt subcommand A-98
tcp status subcommand A-98
tcp syndata subcommand A-98
tcp trace subcommand A-98

tcp window subcommand A-99
telnet command
 description A-101
 examples A-101
Telnet, key sequences, table 3-6
terms, defined D-1
time command
 description A-102
 examples A-102
tip command
 description A-103
 diagnostics A-103
trace ascii subcommand A-106
trace broadcast subcommand A-106
trace command
 description A-105
 examples A-106
trace hex subcommand A-106
trace input subcommand A-105
trace off subcommand A-105
trace output subcommand A-105
trace raw subcommand A-106
traceroute, testing network 4-4
transmission frequency
 determining 2-3
 setting 3-9
 table 2-3, A-88

U

udp command
 description A-108
 examples A-108
uptime command
 description A-109
 example A-109
user command
 description A-110
 examples A-112
user config subcommand 3-16, A-110
user create subcommand 3-15, A-110
user delete subcommand A-111
user kill subcommand A-111
user make subcommand A-111
user show subcommand A-111
users
 adding 3-15
 authorization flags 2-12, A-110
 changing authorization options 3-16
 defining 2-12
 defining authorization 3-15

V

version command
 description A-113
 examples A-113
view command
 description A-114
 examples A-114
view session, navigating, table A-114

W

who command
 description A-115
 examples A-115
wireless interface
 configuration example 3-10
 configuring 2-2, 3-8
 IP address 3-7
 link-layer address 2-2
 PN code 2-5
 power level 2-3
 transmission frequency 2-3
worksheet
 configuration 2-12

X

xvi editor, using C-1–C-3

