



## Appendix B

# TAL Proprietary Management Information Base (MIB)

---

The TALnet software supports the standard MIB-II as specified in RFC 1213, "Management Information Base for Network Management of TCP/IP-based internets: MIB-II." TALnet also includes a proprietary TAL MIB. This chapter contains a sample proprietary MIB. Contact TAL to obtain a copy of the latest proprietary MIB.

The TAL proprietary MIB describes the variables that are implemented for TALnet. The MIB relies on RFC 1155, "Structure and Identification of Management Information for TCP/IP-based Internets," and uses the format described in RFC 1212, "Concise MIB Definitions."

## B.1 General Definitions

This section includes general MIB definitions.

```
TAL-MIB DEFINITIONS ::= BEGIN

    IMPORTS
        MODULE-IDENTITY, OBJECT-TYPE, TimeTicks, enterprises
            FROM SNMPv2-SMI
        DisplayString, PhysAddress, TruthValue
            FROM SNMPv2-TC
        MODULE-COMPLIANCE
            FROM SNMPv2-CONF;

    tal MODULE-IDENTITY
        LAST-UPDATED      "9512130017Z"
        ORGANIZATION      "Tetherless Access Ltd."
        CONTACT-INFO      "Thorsten Lockert
                           Tetherless Access Ltd.
                           930 East Arques Avenue
                           Sunnyvale, CA 94086-4552

                           Phone: (408) 523 8000
                           Fax  : (408) 523 8001

                           Email: tholo@tetherless.com"
        DESCRIPTION      "The MIB module for TAL equipment"
        ::= { enterprises 1110 }
```

```
products          OBJECT IDENTIFIER ::= { tal 1 }
local             OBJECT IDENTIFIER ::= { tal 2 }

talk              OBJECT IDENTIFIER ::= { local 1 }
```

Some network management tools such as HP OpenView cannot read the previous MODULE-IDENTITY section. If you are using such a tool, replace that section (beginning with the line `tal MODULE-IDENTITY` and ending with the line `::= { enterprises 1110 }`) with the following text:

```
tal OBJECT IDENTIFIER ::= { enterprises 1110}
```

## B.2 TAL Products

The following is the product section of the TAL-proprietary MIB. The product section contains the different product's object identifiers. Each product has a unique object identifier allocated from this section which is referenced by the *sysObjectID* variable from RFC 1156, "Management Information Base for Network management of TCP/IP-based internets." New products will be added at the end of this list.

```
subspace-2001     OBJECT IDENTIFIER ::= { products 1 }
```

## B.3 TAL Local Variables

The following is the variable section of the TAL-proprietary MIB. The variable section describes the local variables within the TAL product line. Groups might or might not be present depending on the software options present in the managed device.

```
talkNumber OBJECT-TYPE
    SYNTAX  INTEGER
    ACCESS  read-only
    STATUS  mandatory
    DESCRIPTION
        "Number of TALK interfaces configured."
    ::= { talk 1 }
```

## B.4 TALtalk Radio Table

The following is the TALtalk radio table:

```
talkRadioTable OBJECT-TYPE
    SYNTAX  SEQUENCE OF TalkRadioEntry
    ACCESS  not-accessible
    STATUS  mandatory
    DESCRIPTION
        "List of TALK interfaces on the system."
    ::= { talk 2 }
```

```
talkRadioEntry OBJECT-TYPE
    SYNTAX TalkRadioEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "Collection of objects specific to a TALK interface."
    INDEX { talkRadioIndex }
    ::= { talkRadioTable 1 }
```

```
TalkRadioEntry ::=
    SEQUENCE {
        talkRadioIndex
            INTEGER,
        talkRadioName
            DisplayString,
        talkRadioAddr
            PhysAddress,
        talkRadioDataRate
            Gauge,
        talkRadioMaxDialog
            INTEGER,
        talkRadioMaxLatency
            INTEGER,
        talkRadioSlotTime
            INTEGER,
        talkRadioCrowd
            Gauge,
        talkRadioInputHellos
            Counter,
        talkRadioOutputHellos
            Counter
    }
```

```
talkRadioIndex OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Interface index of this TALK interface."
    ::= { talkRadioEntry 1 }
```

```
talkRadioName OBJECT-TYPE
    SYNTAX DisplayString
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Symbolic name of the radio interface"
    ::= { talkRadioEntry 2 }
```

```
talkRadioAddr OBJECT-TYPE
    SYNTAX  PhysAddress
    ACCESS  read-only
    STATUS  mandatory
    DESCRIPTION
        "Link-level address of this TALK interface."
    ::= { talkRadioEntry 3 }

talkRadioDataRate OBJECT-TYPE
    SYNTAX  Gauge
    ACCESS  read-only
    STATUS  mandatory
    DESCRIPTION
        "Data rate of this TALK interface in bps"
    ::= { talkRadioEntry 4 }

talkRadioMaxDialog OBJECT-TYPE
    SYNTAX  INTEGER
    ACCESS  read-only
    STATUS  mandatory
    DESCRIPTION
        "Maximum time this TALK interface will attempt to send
        a packet."
    ::= { talkRadioEntry 5 }

talkRadioMaxLatency OBJECT-TYPE
    SYNTAX  INTEGER
    ACCESS  read-only
    STATUS  mandatory
    DESCRIPTION
        "Maximum processing delay for a packet to enter and leave
        the router."
    ::= { talkRadioEntry 6 }

talkRadioSlotTime OBJECT-TYPE
    SYNTAX  INTEGER
    ACCESS  read-only
    STATUS  mandatory
    DESCRIPTION
        "Interval to wait before attempting radio transmission."
    ::= { talkRadioEntry 7 }

talkRadioCrowd OBJECT-TYPE
    SYNTAX  Gauge
    ACCESS  read-only
    STATUS  mandatory
    DESCRIPTION
        "Number of adjacent radios that have sent data in the
        last 10 second sampling period."
    ::= { talkRadioEntry 8 }
```

```

talkRadioInputHellos OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Number of HELLO messages received from nearby stations."
    ::= { talkRadioEntry 9 }

talkRadioOutputHellos OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Number of HELLO messages broadcast from this TALK radio
        interface."
    ::= { talkRadioEntry 10 }

```

## B.5 TALtalk Neighbor Table

The following is the TALtalk neighbor table:

```

talkNeighborTable OBJECT-TYPE
    SYNTAX SEQUENCE OF TalkNeighborEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "List of adjacent TALK neighbors."
    ::= { talk 3 }

talkNeighborEntry OBJECT-TYPE
    SYNTAX TalkNeighborEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "Collection of objects specific to TALK neighbors."
    INDEX { talkNeighborAddress, talkNeighborRadioIndex }
    ::= { talkNeighborTable 1 }

TalkNeighborEntry ::=
    SEQUENCE {
        talkNeighborAddress
            PhysAddress,
        talkNeighborRadioIndex
            INTEGER,
        talkNeighborStatus
            INTEGER,
        talkNeighborLastChange
            TimeTicks,
        talkNeighborLastDialog
            TimeTicks,
        talkNeighborOutOctets
            Counter,
        talkNeighborOutDialogRequests
            Counter,

```

## TALtalk Neighbor Table

---

```
talkNeighborOutDialogFails
    Counter,
talkNeighborOutConfirmTimeout
    Counter,
talkNeighborOutAckTimeout
    Counter,
talkNeighborInOctets
    Counter,
talkNeighborInDialogRequests
    Counter,
talkNeighborInDialogOKs
    Counter,
talkNeighborInDataTimeouts
    Counter,
talkNeighborSuspectCount
    Counter
}

talkNeighborAddress OBJECT-TYPE
    SYNTAX PhysAddress
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Link-level TALK address of this neighbor."
    ::= { talkNeighborEntry 1 }

talkNeighborRadioIndex OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Neighbor index of this neighbor entry."
    ::= { talkNeighborEntry 2 }

talkNeighborStatus OBJECT-TYPE
    SYNTAX INTEGER {
        candidate(1), -- Possible adjacency
        good(2),      -- Adjacent
        suspect(3),   -- Unstable
        dead(4)       -- Declared dead
    }
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Enumeration:
            1 - Candidate: Possible adjacency detected; verifying
            2 - Good:      Adjacency established
            3 - Suspect:   Adjacency unstable
            4 - Dead:      Adjacency declared dead"
    ::= { talkNeighborEntry 3 }
```

---

```
talkNeighborLastChange OBJECT-TYPE
    SYNTAX TimeTicks
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Time elapsed since last neighbor status change."
    ::= { talkNeighborEntry 4 }

talkNeighborLastDialog OBJECT-TYPE
    SYNTAX TimeTicks
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Time elapsed since last completed TALK dialog with this
neighbor."
    ::= { talkNeighborEntry 5 }

talkNeighborOutOctets OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Number of octets sent to this neighbor."
    ::= { talkNeighborEntry 6 }

talkNeighborOutDialogRequests OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Number of packets sent to this neighbor."
    ::= { talkNeighborEntry 7 }

talkNeighborOutDialogFails OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Number of TALK dialogs with this neighbor that failed
to complete."
    ::= { talkNeighborEntry 8 }

talkNeighborOutConfirmTimeout OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Number of TALK bandwidth reservation requests that
went unanswered."
    ::= { talkNeighborEntry 9 }
```

## TALtalk Neighbor Table

---

```
talkNeighborOutAckTimeout OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Number of TALK data transmissions that went un-
        acknowledged."
    ::= { talkNeighborEntry 10 }

talkNeighborInOctets OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Number of octets received from this neighbor, directed to us."
    ::= { talkNeighborEntry 11 }

talkNeighborInDialogRequests OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Number of bandwidth reservation requests received from this
        neighbor, directed to us."
    ::= { talkNeighborEntry 12 }

talkNeighborInDialogOKs OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Number of packets received from this neighbor, directed
        to us."
    ::= { talkNeighborEntry 13 }

talkNeighborInDataTimeouts OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Number of reservation requests that were not followed by
        valid data packets."
    ::= { talkNeighborEntry 14 }

talkNeighborSuspectCount OBJECT-TYPE
    SYNTAX Counter
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Number of times this neighbor's status has been marked
        'suspect'."
    ::= { talkNeighborEntry 15 }
```

## B.6 TALtalk Channel Table

The following is the TALtalk channel table:

```

talkChannelTable OBJECT-TYPE
    SYNTAX SEQUENCE OF TalkChannelEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "List of radio channels which may be used by TALK."
    ::= { talk 4 }

talkChannelEntry OBJECT-TYPE
    SYNTAX TalkChannelEntry
    ACCESS not-accessible
    STATUS mandatory
    DESCRIPTION
        "Collection of objects specific to a TALK radio channel."
    INDEX { talkChannelIndex, talkChannelRadioIndex }
    ::= { talkChannelTable 1 }

TalkChannelEntry ::=
    SEQUENCE {
        talkChannelIndex
            INTEGER,
        talkChannelRadioIndex
            INTEGER,
        talkChannelName
            DisplayString,
        talkChannelPower
            INTEGER,
        talkChannelFixed
            TruthValue,
        talkChannelNumber
            INTEGER,
        talkChannelPNCCode
            INTEGER
    }

talkChannelIndex OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Index of this channel"
    ::= { talkChannelEntry 1 }

talkChannelRadioIndex OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Index of associated radio table entry"
    ::= { talkChannelEntry 2 }

```

## TALtalk Channel Table

---

```
talkChannelName OBJECT-TYPE
    SYNTAX DisplayString
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Symbolic name assigned to this channel."
    ::= { talkChannelEntry 3 }

talkChannelPower OBJECT-TYPE
    SYNTAX INTEGER (0..100)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Power output of this channel, expressed as a whole
        percentage of maximum power."
    ::= { talkChannelEntry 4 }

talkChannelFixed OBJECT-TYPE
    SYNTAX TruthValue
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "TRUE if the power output of this channel is fixed."
    ::= { talkChannelEntry 5 }

talkChannelNumber OBJECT-TYPE
    SYNTAX INTEGER
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Channel number (radio specific) used for transmitting
        on this channel."
    ::= { talkChannelEntry 6 }

talkChannelPNCode OBJECT-TYPE
    SYNTAX INTEGER (1..8)
    ACCESS read-only
    STATUS mandatory
    DESCRIPTION
        "Pseudo-Noise code used for transmitting on this channel."
    ::= { talkChannelEntry 7 }
```